



Installation Instructions for Chain Gates

There are two different mounting styles of chain gates. One mounts on the inside header (VW-700) while the other mounts in the jamb (VW-700A). It is important to understand how the gate will mount and order appropriately.

VW-700 Mounting Typical--- curb side locking

Secure the angle (C.G. 14), with the pin on top towards passenger side, to the inside of the opening on driver's side of vehicle.

Slide pipe (C.G.11) over pin on secured angle (C.G. 14), slide on chain rings (C.G.13) and lead bar (C.G. 8), insuring that the point of the lock assembly points towards the passenger side. Secure cast iron bracket pin (C.G.10) with the loop hook up, to right angle bracket (C.G. 12). Secure Right angle bracket (C. G. 12) to inside face on passenger side.

Secure locking plate (C.G. 5) to passenger side door jamb at correct level. NOTE: Lead bar MUST be in the secure position on the loop hook before securing locking plate (C.G. 4)

Attach chain body (C.G. 15) to top chain rings, starting on driver's side working your way towards the passenger side. Secure chain body (C.G. 15) to angle bar (C.G.14) and then to lead bar (C.G. 8) while pinching to close stationary loop rings (C.G. 7).

Attach curtain (optional) to chain body on inside using attached snap rings.

VW-700A Mounting Typical --- curb side locking

Secure the angle (C.G. 14), with the welding pin on top towards passenger side, to the jamb of the opening on driver's side of vehicle.

Slide pipe (C.G.11) over pin on secured angle (C.G. 14), slide on chain rings (C.G.13) and lead bar (C.G. 8), insuring that the point of the lock assembly points towards the passenger side. Secure cast iron bracket pin (C.G.10) with the loop hook up, to (C.G.12) bracket.

Secure locking plate (C.G. 4) to passenger side door jamb at correct level. NOTE: Lead bar MUST be in the secure position on the loop hook before securing locking plate (C.G. 5).

Attach chain body (C.G. 15) to top chain rings, starting on driver's side working your way towards the passenger side. Secure chain body (C.G. 15) to angle bar (C.G.14) and then to lead bar (C.G. 8) while pinching to close stationary loop rings (C.G. 7).

Attach curtain (optional) to chain body on inside using attached snap rings.

CHAIN GATE PARTS LIST

