



OPERATION MANUAL FOR CRITERION STEEL FOLDING GATES

EG and DC Gates with Folding Bottom Tracks



WARNING! – Moving gate can cause SERIOUS INJURY

- Do NOT reach through or climb on or over gate
- Open and close gate and raise and lower track with caution
- Avoid pinch points
- Operate gate only when area is clear of people and obstructions

- To Lock Gate:
1. Release bottom track from folded position by slightly lifting the lock arm and carefully resting the bottom track on the floor. Be sure that the end of the track is securely set into the saddle of the lock post on a single gate, or the saddle of the opposite track on a pair of gates.
 2. Draw the gate from the racked position and gently pull until it is fully extended. Never force the gate if it doesn't pull smoothly (Repeat for second half if pair of gates).
 3. Lock gate to opposite anchor bar by using the key in the cylinder lock, or padlock if so provided.

- To Open Gate:
1. Unlock cylinder lock or remove padlock.
 2. Firmly push gate all the way into the fully racked position.
 3. Raise up bottom track and carefully position lock arm catch to positively hold bottom track up.
 4. If gate pivots, swing gates into final rack position (repeat steps one through four if pair of gates).

NOTE: For gates without bottom track, omit above steps related to bottom track.