SUPPLEMENTAL INSTALLATION INSTRUCTIONS DOORS WITH ISOLATION MOUNTS

- 1. Cut isolation strips to match length of wall/filler angles.
- 2. For face of wall mount doors and grilles -

Peel off adhesive liner and attach strips to wall side of <u>wall angles</u> at the heel and toe as shown. If mounting to a narrow jamb shift the heel side strip closer to the wall bolt so both strips are fully on the mounting surface.

For between jamb mount doors and grilles -

Peel off adhesive liner and attach strips to wall side of filler angles at the heel and toe as shown.

- 3. Locate wall/filler angles per installation instructions. Set wall/filler angles 1/4" minimum off floor.
- 4. For masonry jambs -

Secure wall/filler angles to wall using appropriate wedge/sleeve anchors. Tighten anchors, then remove nut and install an isolation washer against the wall/filler angle and a steel fender washer* on top of the isolation washer as shown, re-tighten anchor with a ratchet or box/open end wrench.

For steel or wood jambs -

Secure wall/filler angles to wall using appropriate fasteners with an isolation washer against the wall/filler angle and a steel fender washer* on top of the isolation washer as shown. Tighten fasteners with a ratchet or box/open end wrench.

*With 1/2" fasteners, a 1/2" steel flat washer that fully covers the isolation washer can be used and the 3/8" steel fender washer can be omitted.

IMPORTANT NOTES:

Do not tighten fasteners with an impact wrench or other power tools - Use a ratchet or box/open end wrench

Do not overtighten fasteners - Compress but do not crush isolation strips or washers. BUILDING NEOPRENE STRUCTURE STRIP PEEL ADHESIVE TOE HEEL LINER OFF STRIP AND APPLY TO WALL/FILLER ANGLE WALL ANGLE NEOPRENE WASHER STEEL FENDER WASHER WALL BOLT 1/4 NUT MIN. APPLY ISOLATION STRIPS SET WALL ANGLE OFF FLOOR **INSTALL ANCHORS** FILLER ANGLE WALL WALL WALL **ANGLE** ANGI F **ANGLE**



Z-GUIDE

(Masonry mount)

ISO INSTALL-05/24

BETWEEN JAMB MOUNT

E-GUIDE

(Non-Masonry mount)