

INSTALLATION INSTRUCTIONS for LT SERIES FOLDING GATE

REVIEW ALL INSTRUCTIONS COMPLETELY BEFORE ATTEMPTING INSTALLATION

1. PLACE MOUNTING ANGLE ON FLOOR AND MARK THE HOLE ON THE GROUND. DRILL A 5/8" HOLE 2" DEEP. (FIG. 1)
2. PLACE STACKED GATE WITH THE LOWER PIVOT PIN IN THE 2" DEEP HOLE.
3. PLACE MOUNTING ANGLE OVER THE UPPER PIVOT PIN AND PLACE GATE IN PLUMB POSITION. (FIG. 2)
4. MARK THE WALL FOR THE (2) MOUNTING BOLTS. THEN REMOVE GATE AND DRILL HOLES FOR MOUNTING ANGLE. (FIG. 2)
5. RETURN GATE WITH LOWER PIVOT IN THE 2" DEEP HOLE IN GROUND AND PLACE MOUNTING ANGLE OVER THE UPPER PIVOT PIN AND BOLT SECURELY TO THE WALL.
6. IF THIS IS A SINGLE GATE, PULL GATE ACROSS TO OPPOSITE WALL AND MARK WALL FOR HOLE LOCATIONS FOR MOUNTING THE LOCK POST. (FIG. 3)
NOTE: BE SURE TO ALIGN PADLOCK OR CYLINDER LOCK LOCATION ON LOCK POST WITH SAME ON LEAD BAR OF GATE.
 A. IF GATE IS BI-PARTING REPEAT STEPS 1 THROUGH 5 ABOVE AND PROCEED TO STEP 7 BELOW.
7. HAVING MOUNTED BOTH SEGMENTS OF THE GATE, PULL THE TWO TOGETHER SO THAT THE LEAD BARS ARE IN CONTACT WITH EACH OTHER. MAKE SURE THE DISTANCE OF THE LEAD BARS IS THE SAME AS THOSE MOUNTED ON ONE OF THE WALLS. DROP THE CANEBOLT TO THE FLOOR AND MARK THE LOCATION OF CONTACT. DRILL HOLE 3" DEEP (DRILL HOLE ADDITIONAL 1" TO 2" DEEP FOR POSSIBLE ACCUMULATION OF DEBRIS.)




FIG. 1




FIG. 2








FIG. 3



TYPICAL MOUNTING ARRANGEMENT IS SHOWN. MODIFICATIONS MAY BE REQ'D DUE TO FIELD CONDITIONS

